



BA 012 LAMPGUARD

HOLD LAMPGUARD IN DESIRED POSITION MARK THROUGH THE PRE DRILLED HOLES IN LAMPGUARD PILOT DRILL AND ATTACH WITH THE SELF TAPPING SCREWS SUPPLIED.



IMPORTANT NOTICE

PLEASE ENSURE THE FITTING OF ANY FRONTAL PROTECTION SYSTEM DOES NOT CONTRAVENE ANY LOCAL LEGISLATION REGARDING USE ON PUBLIC HIGHWAYS.