



The quality parts for Land Rovers

Fitting Instructions

Important Information - Please read this sheet prior to commencing fitment of this radiator.

When fitting a Britpart supplied BTP1823S radiator, you will need to replace the existing four rubber grommets on the radiator side of the cradle (two top and two bottom) with those supplied with your new radiator. The grommets on the intercooler side do not need to be changed.

