

HARDTOP TROLLEY & COVER

Universal Fit

Part Number: MXV1120X



1. Locate the 2 long cross bars with the hole in the center and fasten them together in the center with one of the 5/16"x 3/4" bolts, 2 washers and acorn nut. This is going to make the cross bracing for the back of the cart.
2. Stand the base frame pieces in their upright position and locate the bar with the foam in the center. Attach one end of the cross brace assembly from step one along with one end of the cross bar and fasten to the upper most (threaded) hole on the back of the frame with one of the 5/16" x 3/4" bolts and washer supplied. Now attach to the other base frame with the bolt and washer supplied.
3. Connect the other ends of the cross bracing to the holes on the back of the frame using the 5/16" x 1 3/8" bolts, washers, and nuts supplied.
4. Put all 4 castors into place but do not put the nuts on the top yet. Use the 2 remaining cross bars and run them from side to side on top of the frame over the studs coming up from the castors. Now put the nuts on and tighten all nuts.

