

STEERING GUARD – STEEL

Terrafirma

Discovery 1 & Range Rover Classic

Winch Bumper Compatible



Part Number: **RA1225STF & RA1225ATF**

1. Offer the two side arms of the steering guard up to the chassis rails.
2. Bolt the arms to the inside of the chassis rails using the bolt holes for the lashing eyes, one of the bolts that secures the steering box and the spare hole in the chassis rail.



3. Offer up the front guard to the two side brackets and bolt together but do not tighten yet.
4. Ensure that the guard is square and level; when you are happy, fully tighten all bolts.



QUALITY PARTS AND ACCESSORIES



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA,
England Telephone: 01522 568000 | E-mail: sales@rimmerbros.com

www.rimmerbros.com

Registered in England No 1234567 | VAT No: 1234567