

TREAD PLATE

Triumph TR2-6

Part Number: **RF4129**



1. Slip the flat edge of the plate under the rubber trim strip on the inside edge of the threshold.
2. Press down and in.
3. Drill through the pilot holes with a 2.5mm drill bit.
4. Install the sheet metal screws provided.

QUALITY PARTS AND ACCESSORIES



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA, England

UK Tel: +44 (0)1522 568000 | USA Tel: 1 855 746 2767 | Fax: +44 (0)1522 567600 | E-mail: sales@rimmerbros.com

www.rimmerbros.com