

## KNUCKLE JOINT ASSEMBLY – Redesigned Lower (Pair) MGF

**Part Number: RGG001219P1**



When fitting, ensure that the top arm socket for the knuckle joint is thoroughly cleaned of any rust or debris. If housing is tight in the arm, then use a rotary abrasive flap wheel to sand the inner housing.

To fit the grease nipple, drill and tap an M6 hole in the centre top arm socket and fit the grease nipple from below.

At service interval, support the car so the suspension load is off and then grease.

Remove nipple and fit blanking screw and washer. Do not over grease in use as it can force off the rubber boot.

The ball and socket mating faces must be greased when fitting.

Refit spacing washing and spring from old unit to give correct ride height. \*NB – Front and rear spacing washers are different thickness so do not confuse.

