



**FITTING INSTRUCTIONS**

**34J**

34J Contains:	
4 x 34J Poly Pieces	2 x 34J Washers
2 x 1C Tubes	2 x 1X Washers
2 x 34J Flange Plate	

Step 1:  
Remove existing bushes from the differential.

Step 2:  
Assemble the bush as shown in the diagram. (A & B)

Step 3:  
Depending on the mounting pins fitted to the vehicle, the 34J is supplied with 2 different types of the washers. **A standard vehicle with OEM mounting studs will need the smaller ID washers.** Some vehicles may have uprated mounting studs which have a larger OD. This setup will required the larger ID of the 2 styles of washer.

**NOTE:** The unused washer is not required.

Step 4:  
Mount the bushes to the differential ensuring the flange plate is to the underside of the diff. Loosely fit the bolts.

Step 5:  
Lift the differential into position and algin with the mounting studs.

Step 6:  
Using the correct washer for your vehicle, place the washer beneath the bush and fit the nut below. (C)

Step 7:  
Torque to the 2 nuts to manufactures settings.

Step 8:  
Ensure the differential is aligned and then torque the mounting flange bolts to manufactures settings.

