

## **Steps for Installing Mountney Steering Wheel with Boss Hub In MGB with Center Horn Push**

- 1. Remove original steering wheel**
- 2. Remove slip ring horn contact from bottom of original hub (2 screws)**
- 3. Prepare 8" single flexible wire (strip both ends to metal)**
- 4. Using small flat head screwdriver lift metal piece on slip ring and insert one end of stripped wire under metal piece.**
- 5. Using needle nose pliers bring metal piece down to make friction pressure on wire end.**
- 6. Run wire through hole in slip ring (where original pen contact was located)**
- 7. Using sandpaper, remove paint covering on Mountney horn push assembly contact.**
- 8. Using sandpaper, remove paint on inside of Boss Hub where Mountney horn push contact will make contact inside Boss Hub.**
- 9. Attach end of 8" wire to metal contact on bottom of Mountney horn push assembly.**
- 10. Position Steering Wheel and secure with locking bolt.**
- 11. Push horn button and horn will operate.**

**The above procedure will allow the electrical circuit to be closed which will allow the horn to operate using the Mountney Boss Hub assembly.**