

BODY

WINDSCREEN

– Remove and refit


76.81.01

Removing

1. Remove the wiper arms. 84.15.01.
2. Remove the interior mirror – two screws.
3. Push the finisher covers to one side to expose the joints, using a suitable piece of wood.
4. Carefully ease the finishers from the weatherstrip.
5. Break the seal, using a suitable blunt tool.
6. Push the glass outwards.


CAUTION: Take care to avoid scratching the glass.

7. Remove the weatherstrip.



Refitting

8. Clean all traces of old sealing compound from the screen aperture flange, using petrol or white spirit.
9. Apply Seelastik SR51 to the glass channel and fit the weatherstrip to the screen.
10. Insert a strong cord into the weatherstrip inner channel allowing the ends to protrude from the lower edge.
11. Have an assistant position the glass centrally in the aperture and maintain a steady pressure whilst the cord ends are pulled to locate the weatherstrip on the body flange.
12. Seal the outer channel of the weatherstrip to the body using Seelastik SR51.
13. Sparingly apply rubber grease or soap/water solution to the weatherstrip finisher recess.
14. Assemble the two finisher covers to the left hand finisher.
15. Fit the finishers using the special tool as follows:
 - a. Locate the tool in the recess with open end uppermost and in a vertical position.
 - b. Keeping the hook firmly engaged in the recess, draw the tool along to engage the inner flange of the weatherstrip with the finisher.
16. Push the cover finishers centrally over the joints.
17. Fit the interior mirror and wiper arms.



FINISHER STRIP INSERTION TOOL

To fabricate finisher strip insertion tool.

1. Shape a piece of mild steel rod as shown, paying particular attention to the form of the tip. Ensure that the tip is fully rounded and free from burrs.
2. Braze the hook into a metal stock.
3. Fit stock into a file handle and secure with a rivet.

