

SISA DESIGN WINNDEFLECTOR.™

Patented / tv tested.

Fitting instructions for: Triumph TR 7-8

The windstop consists of the following parts:

1. Shield (Polycarbonate) with frame.
2. 2 brackets -2 bracket holders
3. Storage bag.

Fitting:

- Open the hood cover.
- Remove temporarily the safety-belt holder on the console by taking out the screw under the plastic cap.
- Place the bracket holder under the safety belt holder, repeat this also at the other side.
- Push the brackets in the side of the winddeflector, put the winddeflector in his place.
- Remove the foil from the shield.

