

Fitting Instructions: Wheel Arch Protectors - Discovery 3 Door
(LRD153 / 154)

Kit Contents:

Four piece set of wheel arch protectors
Rubber Finishing Strips

Tools required:

Masking tape
Degreaser
Spatula
Adhesive (Land Rover ref. no. STC8187) NB Land Rover product number supplied for reference only.

IMPORTANT:

Please read through all instructions and ensure that they are understood before undertaking fitting of the product.

Ensure that all the contact areas of the mouldings are spotlessly clean and free of wax or grease.

Test the suitability of panel cleaner on an inconspicuous part of the vehicle i.e underside of the bonnet.

Ensure that the manufacturers instructions relating to adhesive application are correctly followed i.e. humidity and temperature conditions,

- Degrease the areas on the bodywork where the wheel arch protectors will be adhered.
- Select a wheel arch to commence fitting and lay the wheel arch protector face down on a protective surface i.e. cloth.
- Apply the adhesive to the arch protector along its complete length and using the spatula spread the adhesive liberally and evenly over the entire face. Take care not to spread the adhesive over the edge of the arch protector as this may result in smearing of adhesive over bodywork. (If accidental leakage occurs white spirit will remove the excess adhesive from panels and arch protectors.) Do NOT use panel wipe on arch protectors.
- Moving along the wheel arch, locate the lip on the arch protector to the underneath of the wing. Gently press the arch protector onto the face of the body panel. In order to prevent the arch protector from slipping whilst adhesive sets, apply strips of masking tape across arch protector onto the bodywork.

Leave to bond for a minimum of 4 hours.

Repeat instructions for the remaining 3 arches.

DO NOT wash the vehicle for a minimum of 24 hours.