

## RELAY 20a 12V FIVE TERMINAL


TR6 (Hazard), TR7 (Starter), Jaguar E-Type 70-71 (Starter), XJ6 1971 (Starter Ballast)

Part Number: **148643**




Originally a rectangular metal can with 5 terminals on the bottom, the relay (1A) evolved as Lucas updated designs.

The functional relationship of the contacts is shown in (1B)




One of the more recent versions, the SRB400, was a bright blue plastic can with 5 terminals on the bottom. Lucas adopted standard relay terminal designations, and included a slip of paper that explained how to relate the old terminal designations to the new.

We scanned that and included a section of it here. (2A)



So how do I hook up the new cube-shaped relay? The bottom of the relay (3A) is shown with the modern as well as the old terminal designations. You will need to refer to the wiring diagram for your vehicle to determine which color wire goes where. Functional relationship is shown in fig 3B.



QUALITY PARTS AND ACCESSORIES



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA,  
England Telephone: 01522 568000 | E-mail: sales@rimmerbros.com

[www.rimmerbros.com](http://www.rimmerbros.com)

Registered in England No 1234567 | VAT No: 1234567